

PRBOX4

TelePRompter ONE

- 1- *Insert Additional Threaded Stud From Bottom of Bracket Assembly Arm Through Slot and Attach to 1/4-20 Tap Located on the Underside of Camera Stacked on Top of Bracket Assembly Arm - Additional Thumb Nuts may be required to Raise Camera In Alignment with PRomptBox® Lens Opening in Frame Back - Refer to Illustration
Do not Adjust PRomptBox® to Camera When Camera is Mounted to an alternate Mounting System
- 2- Insert Longer Threaded Stud Through 1/4-20 Opening Located on the Bottom of the PRomptBox® Frame and Secure Lock Down with Thumb Nut within the Inside Bottom of PRomptBox® Frame

1'

Mount PRomptBox Frame to Tripod/Monopod Before Mounting Camera

- 2- Quick Release Tripod Pan Head and Remove Threaded Screw and Insert Longer Threaded Stud from Under Side of Tripod Pan Head Stack Bracket Assembly Arm on top of Pan Head Through Arm Slot Stack PRomptBox® Frame on Top of Bracket Assembly Arm Secure Lock Down with Thumb Nut within the Inside Bottom of PRomptBox® Frame - Refer to Assembly Overview Video

- 3- Follow Direction * Above for Mounting Camera

Insert Glass Assembly and Device
Lock Down Tablet Top to Back Sides of Frame
Check all Points of Lock Down Including the Threaded Stud and Thumb Screws for Camera Mount, Two Tablet Top Thumb Nuts, Four Frame Thumb Screws,

